




GPS Coordinates

S.No.	Longitude	Latitude
(1)	78°25'52.85"E	28°14'40.75"N
(2)	78°25'52.74"E	28°14'40.59"N
(3)	78°25'52.65"E	28°14'40.46"N
(4)	78°25'52.60"E	28°14'40.39"N
(5)	78°25'52.51"E	28°14'40.25"N
(6)	78°25'52.40"E	28°14'40.09"N
(7)	78°26'00.23"E	28°14'38.81"N
(8)	78°26'07.28"E	28°14'41.26"N
(9)	78°26'14.35"E	28°14'40.96"N
(10)	78°26'25.72"E	28°14'34.09"N
(11)	78°26'32.81"E	28°14'27.18"N
(12)	78°26'36.85"E	28°14'20.54"N
(13)	78°26'42.48"E	28°14'05.41"N
(14)	78°27'07.38"E	28°13'44.60"N
(15)	78°27'41.30"E	28°13'23.49"N
(16)	78°28'20.12"E	28°12'57.07"N
(17)	78°29'15.39"E	28°12'19.15"N
(18)	78°29'38.86"E	28°12'07.77"N
(19)	78°29'57.69"E	28°11'51.67"N
(20)	78°30'03.72"E	28°11'49.91"N
(21)	78°30'13.45"E	28°11'38.29"N
(22)	78°30'13.61"E	28°11'38.42"N
(23)	78°30'13.73"E	28°11'38.53"N
(24)	78°30'13.80"E	28°11'38.58"N
(25)	78°30'13.92"E	28°11'38.69"N
(26)	78°30'14.08"E	28°11'38.83"N
(27)	78°30'35.29"E	28°11'22.74"N
(28)	78°31'02.26"E	28°11'03.93"N
(29)	78°31'17.48"E	28°11'03.12"N
(30)	78°32'03.33"E	28°10'51.46"N
(31)	78°32'14.94"E	28°10'45.26"N
(32)	78°32'21.68"E	28°10'43.57"N
(33)	78°32'27.34"E	28°10'38.08"N
(34)	78°33'08.95"E	28°10'18.33"N
(35)	78°33'56.88"E	28°10'08.94"N
(36)	78°34'38.61"E	28°09'56.19"N
(37)	78°35'18.15"E	28°09'48.49"N
(38)	78°35'47.89"E	28°09'41.11"N
(39)	78°35'47.97"E	28°09'41.29"N
(40)	78°35'48.02"E	28°09'41.44"N
(41)	78°35'48.05"E	28°09'41.51"N
(42)	78°35'48.11"E	28°09'41.66"N
(43)	78°35'48.18"E	28°09'41.84"N

(ई० कर्मवीर सिंह)
सहायक अभियन्ता
ग्रामीण खण्ड, लो०नि०वि०
समनल