





Div. Divisional Engineer (NORTH)
BSNL Roopnagar 140091
(PRITHVI RAJ)

Div. Eng. (Transmission)
B.S.N.L. ROOPAR
(PRAMOD KUMAR)

BSNL LINE MINDWAN TO UPPER BHADDAL LENGTH 2500 METER AND AREA 0.07500 HA



0.001 0 0.001 0.002 0.003 0.004 m




Legend

DGPS MAP


Prithvi Raj
Sub-Divisional Engineer (NOFN)
BSNL Roopnagar 140081
(PRITHVI RAJ)

Pramod Kumar
Div. Eng. (Transmission)
B.S.N.L. ROPAR
(PRAMOD KUMAR)




(Signature)
Div. Eng. (Transmission)
B.S.N.L. ROPAR
140051
(PRITHVI RAJ)

(Signature)
Div. Eng. (Transmission)
B.S.N.L. ROPAR
(PRAMOD KUMAR)




(Signature)
Sub. Divisional Engineer
BSNL Roopnagar 140091
(PRITHVI RAJ)

(Signature)
Div. Eng. (Transmission)
BSNL Roopnagar
(PRAMOD KUMAR)



(Signature)
Sub. Divisional Engineer(NOFN)
BSNL Roopnagar 140091
(PRITHVI RAJ)

(Signature)
Div. Eng. (Transmission)
B.S.N.L. ROPAR
(PRAMOD KUMAR)



(Signature)
Sub. Divisional Engineer (NORTH)
B.S.N.L. Roopnagar 1400031
(PRITHVI RAJ)

(Signature)
Div. Eng. (Transmission)
B.S.N.L. ROJAR
(PRAMOD KUMAR)

BSNL LINE MAJHER TO MAJHER LENGTH 140 METER AND AREA 0.00420 HA

31°12'22"

31°12'22"

31°12'20"

31°12'20"

76.59604,31.20551

76.59631,31.20554

76.59663,31.20561

76.59709,31.20569

76.59746,31.20577

Legend

DGPS MAP


0.0001 0 0.0001 0.0002 0.0003 0.0004 m

76°35'47"

Sub. Divisional Engineer(NOPM)
BSNL Roopnagar 140061
(PRITHVI RAJ)

76°35'49"

Div. Eng. (Transmission)
B.S.N.L. ROPAR
(PRAMOD KUMAR)



BSNL LINE BARUWAL TO MASSEWAL EXCH. LENGTH 2775 METER AND AREA 0.08325 HA

76°35'56"

76°36'29"

76°37'1"

31°12'11"

31°11'38"

76.60414, 31.20156

76.60708, 31.20327

76.61652, 31.20864

76.61845, 31.20841

76.61867, 31.20745

76.59797, 31.19437

Legend
DGPS MAP


0.0025 0 0.0025 0.005 0.0075 0.01 m

31°12'11"

31°11'38"

Sub. Divisional Engineer (Transmission)
B. S.N.L. K. (PRANAV KUMAR)
76°36'29"

Div. Engineer (Transmission)
B.S.N.L. K. (PRANAV KUMAR)
76°37'1"



Sub-Divisional Engineer
BSNL Roopnagar 140001
PRITHVI RAJ

Div. Eng. (Transmission)
B.S.N.L. ROPAR
(PRAMOD KUMAR)